










ZYO-6 Balsa Hand Launch Free Flight Model

Assemble together the parts and paste with little 502 glue at joints.



Display the C.G.



Pls prepare the suitable small screws at the head for adjusting the C.G.



ZYO-6 Balsawood Free Flight Airplane



★This model is suitable for flying and landing off at soft lawn.

Safety Warnings:

1. Age recommendation: This is not a toy, not for children under 8 years old.
2. Always operate your model in open spaces away from full-size vehicles, traffic and people.
3. Never place any portion of the model in your mouth because the glue is used.
4. Keep away from the children while playing.

